


Slackline 2M Jungle Rope











1	78605015		1 x	140mm x 1760mm	17.00 kg
2	76701006	0	2 x	85mm x 52mm x 40mm	0.49 kg
3	SW75437		2 x	36mm x 16mm x 16mm	0.02 kg
4	SW92426		2 x	M10x100_8.8 BZP	0.07 kg
5	8008850		4 x	Washer, Bolt cap 11x24x2- ISO4759-3-C	0.006 kg
6	SW91094		4 x	Nylon Washer 33mm x 94mm x 2.5mm	0.002 kg
7	8008796		2 x	Nut, Fujilok-M10-8-RingA2	0.011 kg
8	SW79289		4 x	M10 Security Cap Bottom	0.01 kg
9	SW79290		4 x	M10 Security Cap Top	0.01 kg

















-les retirer avant bétonnage


MA76701005




















▲ WARNING

Playground equipment installed over hard surfaces such as concrete, asphalt or packed earth may result in serious injury or death from falls. Make sure that appropriate safety surfacir is present, before allowing children to play.

▲ WARNING

Children have strangled and died while their dothes caught on slides and other playgroun equipment. Before allowing children to play, remove helmets, scarves, necklaces, hood cords, neck drawstrings, and mittens connected through the sleeves. Also, remove any foreign ropes, strings, or shore laces that may be led to equipment.

▲ WARNING

All playground equipment and rubber surfacir may become hot enough to cause burns. Check for hot surfaces before allowing childre to play. Children should wear appropriate shops at all times.

▲ WARNING

Playing tag or running on or under playgroun equipment can lead to serious injuries from falls, collisions, and head strikes. do not run on or under playground equipment. Pay attention while playing and be careful.

"play smart" rules

✓ Do not play on broken or damaged equipment. Report it.
✓ Do not play without adequate safet surfacing below and around equipment.
✓ No helmets, necklaces or drawstring should be worn while on equipment.
✓ Be careful of hot paly surfaces and always wear shoes while playing.
✓ Do not play tag or run on playgroun.

✓ Do not play tag or run on playgrou equipment and do not jump off of equipment.

✓ Watch your head! Do not run under bridges, decks, stairs, or othe equipment.


✓ Be careful when equipment is wet.
Do not play on snowy or icy equipment.
 ✓ Do not climb on roofs, railings, or posts, or on top of crawl through tube

✓ Slide sitting down, feet first, and o at a time. Do not slide up chutes or tubes.


Adults – do not slide with a child on your lap. It can injure your child's legs.

Before letting go of overhead bars, hang down still, bend your knees a little and drop straight down with both feet.

Swing sitting down and do not jump out while swinging. Do not twist chains.











▲ WARNING

Playground equipment installed over hard surfaces such as concrete, asphalt or packed earth may result in serious injury or death fror falls. Make sure that appropriate safety surfacir is present, before allowing children to play.

▲ WARNING

Children have strangied and died while their dothes caught on sildes and other playgroun equipment. Before allowing bildren to play, remove helmets, scarwes, necklacas, hood cods, nexid crawstrings, and mittens connected through the sleeves. Also, remove any foreign ropes, strings, or shore laces that may be fed to equipment.

MARNING

All playground equipment and rubber surfacin may become hot enough to cause burns. Check for hot surfaces before allowing childre to play. Children should wear appropriate shops at all times

▲ WARNING

Playing tag or running on or under playgroun equipment can lead to serious injuries from falls, collisions, and head strikes. do not run on or under playground equipment. Pay attention while playing and be careful.

'play smart" rules

Didy Small Tures

/ Do not play on broken or damaged
equipment. Report it.

/ Do not play without adequate safet
surfacing below and around equipment
/ No helmets, necklaces or drawstring
should be worn while on equipment.
/ Be careful of hot paly surfaces and

always wear shoes while playing.

✓ Do not play tag or run on playgrour equipment and do not jump off of

 Watch your head! Do not run inder bridges, decks, stairs, or othe quipment.

✓ Be careful when equipment is wet. Do not play on snowy or icy equipmen
✓ Do not climb on roofs, railings, or posts, or on top of crawl through tube

✓ Slide sitting down, feet first, and o at a time. Do not slide up chutes or tubes.

Adults – do not slide with a child on your lap. It can injure your child's legs. I Before letting go of overhead bars. hang down still, bend your knees a little and drop straight down with both feet. I Swing sitting down and do not jump out while swinging. Do not twist chains.